

S6161-QQ-FSE-010

REVISION 1

0910-LP-101-4962

TECHNICAL MANUAL

FOR

COOKIE DROPPER, MODEL 17-INCH HANDY;
DESCRIPTION, OPERATION AND MAINTENANCE

“Distribution Statement “A”: Approved for public
release; distribution is unlimited.”

DEPARTMENT OF THE NAVY
NAVAL SEA SYSTEMS COMMAND

2 JULY 2002



0910LP1014962

APPROVAL AND PROCUREMENT RECORD PAGE

APPROVAL DATA FOR: S6161-QQ-FSE-010 Revision 1

TITLE: Technical Manual for Cookie Dropper, Model 17-Inch Handy; Description, Operation and Maintenance

APPROVAL AUTHORITY: Not Required

CONTRACT OR PURCHASE ORDER	SHIP APPLICABILITY	QUANTITY OF MANUALS	QUANTITY OF EQUIPMENT	BUILDING SHIPYARD
4500069104	CVN76	3	1	Northrop Grumman- Newport News

REMARKS:

- 1) Distributed to CVN76 in accordance with Contract No. N00024-95-C-2106, CDRL Item No. B006.

CERTIFICATION: Not Required

Date: July 2, 2002

Bakers' Machinery Co. Inc.
Post Office Box 39
Superior, WI 54880
CAGE No. 19939

IDENTIFYING TECHNICAL PUBLICATION SHEET

1. IDENTIFICATION DATA: MAGNA MIXER COOKIE DEPOSITOR
 MODEL 17" HANDY

2. PURPOSE: THIS TECHNICAL PUBLICATION IS ISSUED FOR THE PURPOSE
 OF IDENTIFYING AN AUTHORIZED TECHNICAL MANUAL FOR
 NAVY USE AND FOR PROVIDING SUPPLEMENTAL
 TECHNICAL INFORMATION.
 - a. MANUFACTURER MAGNA MIXER CO..CINCINNATI, OHIO
 - b. CONTRACT NUMBER: _____
 - c. EQUIPMENT: COOKIE DPOSITOR
 - d. REQUISITION NUMBER:
 - e. NATIONAL STOCK NUMBER (NSN) 7320-01-102-8637
 - f. TITLE OF TECHNICAL MANUAL: OPERATION AND SERVICE MANUAL
 FOR COOKIE DEPOSITOR MODEL 17"
 HANDY
 - g. DATE OF PUBLICATION: 1-5-93
 - h. PREPARING ACTIVITY: MAGNA MIXER CO.
 - i. APPLICABLE TMCR NUMBER:
 - j. EXTENT OF PROPOSED SUPPLEMENT DATA (10% MAXIMUM)
 - k. LIST OF TECHNICAL MANUALS FOR THIS EQUIPMENT PROCURED
 UNDER ANOTHER CONTRACT:

3. ADDITIONAL COPIES: ADITONAL COPIES ARE AVAILABLE FROM

MAGNA MIXER CO.
7811 PALACE DR.
CINCINNATI, OHIO 45249

PUBLICATION NUMBER

LIST OF EFFECTIVE PAGES INSERT LATEST CHANGED PAGES.
 DESTROY SUPERSEDED PAGES.

NOTE: The portion of the text
 affected by the changes is
 indicated by a vertical line
 in the outer margins of the
 page. Changes to illustration
 are indicated by miniature
 pointing hands. Changes to
 diagrams are indicated by
 shaded areas.

Dates of issue for original and changed pages are:
Original:

TOTAL NUMBER OF PAGES IN THIS PUBLICATION IS 30
CONSISTING OF THE FOLLOWING:

Page No.	* Change No.	Page No.	Change No.
1-1 to 1-3	0		
2-1 to 2-3	0		
3-1 to 3-5	0		
4-1 to 4-5	0		
5-1 to 5-5	0		
6-1 to 6-3	0		
7-1 to 7-3	0		
8-1 to 8-3	0		

*Zero in this column indicates an original page.

CHANGE RECORD

Change No.	Date	Title and/or Brief Description	Signature Of Validating Officer
------------	------	--------------------------------	------------------------------------

SAFETY SUMMARY

The following are general safety precautions that are not related to any specific procedures and therefore do not appear elsewhere in this publication. These are recommended precautions that personnel must understand and apply during many phases of operation and maintenance.

KEEP AWAY FROM LIVE CIRCUITS

Operating personnel must at all times observe all safety regulations. Do not replace components or make adjustments inside the equipment with the voltage supply turned on.

DO NOT SERVICE OR ADJUST ALONE

Under no circumstances should any person reach into or enter the enclosure for the purpose of servicing or adjusting the equipment except in the presence of someone who is capable of rendered aid.

RESUSCITATION

Personnel working with or near high voltages should be familiar with modern methods of resuscitation. Such information may be obtained from the Bureau of Medicine and Surgery.

The following warning appears in the text in this volume, and is repeated here for emphasis.

I N T R O D U C T I O N

For more than 70 years Triumph has built wire cut depositors. In this time a vast knowledge has been gained. As a result of this knowledge and field testing, we are proud to present this new development.

In addition to the durability and long life built into Triumph equipment, special attention was given to simplifying the sanitation procedure.

Satisfactory performance of this machine depends on a thorough understanding of its operation, adjustments and proper lubrication. This manual is presented to assist the operator in obtaining the perfection in product and operation he desires. If any question should arise that is not explained to your satisfaction, please call or write to the factory. ,

SERIAL NUMBER 40901

When ordering repair parts, always show this serial number on order.

Reference to serial number will not only eliminate possible error, but also expedites shipment of parts ordered.

TABLE OF CONTENTS

SECTION	PAGE
INTRODUCTION	
I. GENERAL INFORMATION.....	1-1
II. INSTALLATION.....	2-1
III. OPERATON.....	3-1
IV. MAINTENANCE.....	4-1
V. PARTS REPLACEMENT.....	5-1
VI. MOTOR.....	6-1
VII. CONTROLLER.....	7-1
VIII. WIRING DIAGRAM AND DEPOSITOR ASSEM.....	8-1

LIST OF ILLUSTRATIONS

<u>FIGURE</u>	<u>TITLE</u>	<u>PAGE</u>
1-1	OPERATOR SIDE	1-2
1-2	SHUTTLE SIDE	1-3
1-3	TOGGLE SWITCH LOCKING DEVICE	1-4
2-1	CASTERS	2-2
2-2	ADJUSTABLE LEGS	2-2
2-3	DIMENSION DIAGRAM	2-3
3-1	SHUTTLE SIDE	3-2
3-2	CONVEYOR SPEED ADJUSTMENT	3-3
3-3	TOP VIEW OF FINGERS	3-4
3-4	SECTION THRU HOPPER	3-5
4-1	FEED ROLL ASSEM.	4-3
4-2	SHUTTLE SIDE	4-5
4-3	OPERATOR SIDE	4-5
5-1	FEED MECHANISM-TAKEN APART	5-3
5-2	CONVEYOR SPEED ADJUSTMENT	5-5


SECTION 1

GENERAL INFORMATION

PARAGRAPH		PAGE
1	DESCRIPTION	1-2
2	HOPPER	1-2
3	CONVEYOR ADJUSTMENT KNOB	1-2
4	FINGERS AND CUT-OFF WIRE	1-2
5	FEED ROLLS	1-3
6	MOTOR AND DRIVE	1-3
7	SPEED ADJUSTMENT HANDWHEEL	1-3
8	FRAME	1-3
9	TOGGLE SWITCH LOCKING DEVICE	1-4


GENERAL INFORMATION

1. DESCRIPTION: Before operating machine or going into detailed operating instructions it will be helpful to acquaint oneself with the various components of the machine. The operators side is shown on figure 1-1.
2. HOPPER: Fabricated stainless steel, welded, can be tilted toward discharge end of table which brings die plate into an accessible position.
3. CONVEYOR ADJUSTMENT KNOB: Located at the charge end of machine, and controls speed of the conveyor belt only.
4. FINGER AND CUT-OFF WIRE: Fingers are mounted on square finger bar and driven by rocker arms. Correct setting of fingers and wire is very important. See page 3-2 for setting.



DESCRIPTION - Cont'd.

5. FEED ROLLS: Driven by gears through a drive clutch assembly. Feed rolls have a space between the rolls which carry the material to the die with a minimum of pressure. They are mounted in split feed roll bearings for easy removal and cleaning.
6. MOTOR AND DRIVE: Motor mounted on adjustable pivot base. Variable speed sheave is mounted on motor shaft and speed is adjusted by turning the machine speed handwheel. All parts are driven by silent vee belts and roller chain and are accessible through ends of machine frame.
7. SPEED ADJUSTMENT HANDWHEEL: Located at the charge end of machine and controls the speed of entire machine, strokes, and conveyor belt.
8. FRAME: Sheet steel and steel plate fabricated into one solid unit. Space is provided in the base for storage. Frame table, end tables and guards are stainless steel.






FIGURE 1-3

9. --TOGGLE SWITCH LOCKING DEVICE --

FOR CLEANING: BUTT LOCKING PLATE AGAINST TOGGLE
AND TIGHTEN WING SCREW.
POSITION AS SHOWN ABOVE.

FOR OPERATION: LOOSEN WING SCREW AND
SWING LOCKING PLATE 180°
AND TIGHTEN WING SCREW.

SECTION 11
INSTALLATION

PARAGRAPH		PAGE
1	UNCRATING	2-2
2	MOUNTING	2-2
3	DIMENSION DIAGRAM	2-3


INSTALLATION

1. UNCRATING


If depositor was damaged in transit, notify carrier immediately so claim can be made. The depositor is shipped bolted to a skid with four carriage bolts that run thru the skid, up thru the frame base at corners and depositor is covered with a poly vinyl shroud. Remove the shroud and remove the box that holds the casters. NOTE: On some government depositors the casters are replaced with adjustable legs. If depositor has but one die, it will be mounted on the depositor. If it has more than one die, they will be found in a box located inside base of depositor. REMOVE.

2. MOUNTING

The unit weighs approximately 500 pounds and care should be taken when lifting off of skid. Reach into frame and remove the nut and washers off of carriage bolts (do not discard) and lift unit from skid. Tilt one end of frame high enough to slip the caster studs thru holes in frame and lock with the nuts and washers from carriage bolts. Repeat for other end. On Government depositors mount the legs (in place of casters) with the material supplied with the legs. See Figures 2-1 and 2-2.




CASTERS ON
STANDARD DEPOSITORS
FIGURE 2-1





ADJUSTABLE LEGS--SPECIAL
ON GOVERNMENT DEPOSITORS
FIGURE 2-2

INSTALLATION



OPERATOR SIDE

HOPPER CAPACITY : 17 QTS.
STROKES PER MINUTE : 30 TO 70
PAN TRAVEL PER STROKE : 1" TO 5"
COOKIE SHEET UP TO 18" WIDE



*NOTE!

ON GOVERNMENT DEPOSITORS WITH 9" ADJUSTABLE LEGS
IN PLACE OF CASTERS, ADD 4" TO HEIGHT DIMENSIONS SHOWN.

EXTENSION CORD & PLUG

HANDY COOKIE DEPOSITOR

DIMENSION DIAGRAM

FIGURE 2-3

SECTION 111

OPERATION

PARAGRAPH		PAGE
1	ELECTRICAL CURRENT	3-2
2	SETTING OF FINGERS	3-2
3	STARTING	3-3
4	DEPOSIT SPACING	3-3
5	FEED ADJUSTMENT	3-3
6	DEPOSITOR SPEED	3-3
7	LOADING	3-3
8	CORRECTING IMPROPER DEPOSITING	3-4
9	ALIGNING CUT-OFF WIRE	3-5


OPERATION

The depositor is started and stopped by an electrical toggle switch or push buttons. The fingers that carry the cut-off wire can be inched forward by quickly snapping the toggle "ON" or "OFF". If the depositor has magnetic starter with push buttons, hold in on the "STOP" and "START" buttons and quickly operate the "STOP" button in and out.

CAUTION: Keep hands clear of feed rolls and finger drive mechanism when depositor is in operation.


Before placing depositor into production it is beneficial to operate the depositor as though it is in production by completing the following:

1. Be sure to plug into correct electrical current which is 115 volt, 60 HZ., 1 PH with switch in "OFF" position.
2. Inch the finger bar forward as explained in the first paragraph until the leading ends of fingers are close to the die pads, see figure 3-1. Open the feed roll guard by tilting forward from top. Tilt the hopper and attach the die to be used. DO NOT start depositor with hopper tilted as this will damage the depositor. Lower the hopper easily down into operating position, close gear guard, loosen the finger wing screws and slide the fingers on shaft until fingers are between the pads of the die, lock wing screws. See page 3-4 and 3-5 for setting cut-off wire. Use the outer most holes in finger for 3" and larger dies, each successive hole in finger is for dies with holes having smaller than 3" in 1" increments.



OPERATION-Cont'd.

3. Start the depositor by placing the toggle switch in the "ON" position, or by pushing the "START" button.
4. The pans are carried on a pair of belts. The spacing between the row of deposits can be varied as follows:
(a) stop the depositor, (b) pull out on conveyor, adjusting knob, (c) slide sliding lock nut "UP" (to increase spacing) or "DOWN" (to decrease spacing), and release adjusting knob so it can engage detents in the square rod. The gage on square rod are approximate spacing per stroke in inches. DO NOT try to change spacing while depositor is running. See figure 3-2.
5. Feed adjustment (amount of deposit) can be made when the depositor is operating or not. A lock screw is provided so setting is not lost while operating. The indicator plate does not indicate weight but is used for reference only, see figure 1-1, page 1-2.
6. The speed of the depositor, strokes per minute and the conveyor speed can be changed in unison by the machine speed adjusting handwheel, figure 1-2 page 1-3. This adjustment must be made while depositor is running.
7. When loading material into the hopper, distribute the material evenly across entire hopper length to keep even pressure over entire die area. DO NOT, under any circumstance, push down on the material by hand while depositor is operating. If material will not extrude, the formulation will have to be changed slightly, ie. more flour, less flour, more milk or water, etc.




OPERATION-Cont'd.

CORRECTING IMPROPER DEPOSITING

8. Improper adjustment of the cut-off wire may cause some pieces to be deposited upside down, or in irregular rows. The following reference to "Left" and "Right" refer to the sides of the machine when facing it from the "Charge" end of depositor. The front edge of the die is the one you now face and the back edge the one farthest from you, figure 3-3.

Make sure that all the fingers are in line and that the wire is straight and parallel lengthwise with the die. The fingers must be lined up so that the wire is perfectly straight. If any of the four bronze fingers have been bent they must first be straightened. If, for any reason, the outside finger "A" on the left hand side of the machine is too high or too low in relation to the opposite outside finger "B" so that the wire is not parallel lengthwise with the die, finger "A", (left hand side) must be adjusted to line up with finger "B" (right hand side). First loosen the set screw in finger "A" then loosen the lock nuts at "A" and adjust, then tighten the lock nuts and the set screw.



TOP VIEW OF FINGERS


FIGURE 3-3

OPERATION-Cont'd.

ALIGNING CUT-OFF WIRE

9. Make sure that the movement of the wire from front to back is parallel to the face of the die. This is very important. The front edge of the hopper assembly to which the die is attached rests on two screws "C" (one at each end). By loosening the lock nuts and turning the screws "C" the front edge of the hopper, and hence the die can be raised or lowered to make the die parallel with the travel of the cut-off wire. Hopper must be tilted forward to adjust these screws.

After adjusting the screws at both sides for correct height, tighten the lock nuts. Check to make sure the weight of the hopper and die assembly is carried equally on both screws. This can best be done by placing a thin piece of paper between the top of the screws and the hopper. If properly adjusted, both pieces will be held tightly in place by the weight of the hopper and rolls. Make sure that the wire is at the right height in relation to the die. The wire should be set about $1/64$ " lower than the die opening. Both fingers "A" and "B" and the four bronze fingers are raised as a unit when finger "B" (right hand side) is adjusted. To do this loosen the lock nuts on finger "B", make the proper adjustment for height of wire and re-tighten the lock nuts. Set screw in finger "B" should not be disturbed.



SECTION THRU HOPPER

FIGURE 3-4

SECTION IV
MAINTENANCE

PARAGRAPH		PAGE
1	CLEANING	4-2
2	LUBRICATION (DAILY)	4-2
3-6	LUBRICATION (WEEKLY THRU YEARLY)	4-4

MAINTENANCE

1. CLEANING

Before initial operation, and after each day's use, the feed rolls (figure 4-1, page 4-3) must be thoroughly washed and sanitized. Do not delay in cleaning after operating as the material sets which makes taking apart more difficult.

Move the finger shaft assembly so that the finger shaft is away from the hopper section, i.e. toward charge end of depositor. Disconnect from power by removing extension cord from wall receptacle.


Remove the hopper by removing the two wing nuts, one on each bearing cap, see figure 4-1. Replace nuts finger tight. Hinge the gear cover open at far side of hopper by tilting top of cover away from hopper. Tilt feed rolls toward left end by lifting at finger bar side. Loosen the 2 die screw knobs and remove die, then hinge feed rolls back to operating position being careful not to allow it to drop. Remove the two wing nuts, one in each bearing cap at the end of feed rolls. Pull stud pin out of link stud, remove pin washer and slide end of drive link off of lever. Holding it so it does not fall, lower it gently. Lift bearing caps off, then lift each feed roll out.

DO NOT submerge drive clutch at end of drive feed roll in water or direct live steam against it. This precaution is necessary to protect the precision parts from corrosion. Clean all exposed surfaces.

NOTE: When re-assembled feed rolls in machine, place drive feed roll in its bearings. The drive roll is the one with the clutch mounted on the outer shaft. Place the outer (driven) feed roll on top of the driver roll, with gear teeth in mesh, roll the driven feed roll into its bearings. Replace bearing caps, hopper and two wing nuts. Replace the drive link on the link stud, place pin washer on stud and slip stud pin into and thru hole in link stud.

2. LUBRICATION - DAILY

Disconnect power before starting lubrication. Before placing feed rolls back into depositor, if feed roll gears were washed in a sink, brush a light film of edible grease, tallow or salad oil on the gear teeth. Although the nylon bushings on feed roll shafts require no lubrication, the bearing life can be extended by working a film of salad oil between the shaft and bushing. With the end tables in the drop position, place a few drops of oil into the hole on the conveyor shaft bearings, one on each end of shafts.



FEED ROLL ASSEM.

FIGURE 4-1

MAINTENANCE-Cont'd.

3. LUBRICATION-WEEKLY

Once a week brush a light film of grease on top surface of shuttle that is located behind shuttle guard, see Figure 4-2. Check teeth on large crank gear inside of frame on discharge end, if they appear dry brush a light film of grease on the teeth see fig. 4-3, page 4-5.

Using a hand grease gun, grease drive link (both ends) located inside frame. Grease the feed roll link and the adjusting nut, see Figure 4-3. Give 2 or 3 pumps of grease to each grease fitting.

4. LUBRICATION-MONTHLY



Brush a light coat of grease to the feed adjusting screw, wire adjusting screw and speed adjusting screw attached to handwheel, see Figure 4-3.

5. LUBRICATION-3 to 6 MONTHS

Brush the drive chain (located inside frame) with mineral oil. Remove clutch and "O" rings from feed roll shafts and slide nylon bushings off of shafts. Clean up shafts and coat with edible lubricant and replace parts.

6. LUBRICATION-YEARLY

Remove the drive chain (inside frame) and wash in petroleum solvent. Allow chain to soak for 1/2 hour then run thru solvent while flexing joints to remove residue. Wipe off and let dry for an hour. Lay chain in a pan of white mineral oil, flex joints so oil penetrates joints. Let excess oil drain off and replace in depositor.



SECTION V
PARTS REPLACEMENT

PARAGRAPH		PAGE
1.	REPLACEMENT OF FEED ROLL CLUTCH	5-2
2.	REPLACEMENT OF FEED ROLL SHAFT BUSHINGS ...	5-2
3.	REPLACEMENT OF ADJUST. ROCKER ARM BUSH	5-2
4.	REPLACEMENT OF PLAIN ROCKER ARM BUSH	5-4
5.	REPLACEMENT OF DRIVE BELT	5-4
6.	REPLACEMENT OF CONVEYOR BELTS	5-4
7.	REPLACEMENT OF CONVEYOR CLUTCH	5-5

PARTS REPLACEMENT

CAUTION!!! ALWAYS REMOVE EXTENSION CORD FROM POWER WHEN SERVICING

1. TO REPLACE FEED ROLL CLUTCH

To replace the feed roll clutch it is not necessary to remove the feed roll from the depositor. Remove the detent pin and washer from end of link stud, see figure 5-1 page 5-3. Pull feed roll link outward off of link stud and lower link to lowered position. Mark the position of the inner face of the clutch onto the feed roll shaft. Loosen the set screw in clutch inner hub and pull clutch with lever off of shaft.

With clutch removed, remove the three screws that fasten clutch lever to clutch and attach lever to new clutch. Line up keyway in clutch with key in feed roll shaft and slide clutch forward and up to mark on shaft and lock clutch with set screw. Raise feed roll link, line up with link stud and push onto stud. Replace washer and detent pin.


2. TO REPLACE FEED ROLL SHAFT BUSHINGS

To replace bushings it is necessary to remove feed rolls from depositor. There are two wing nuts that hold hopper to feed roll bearings and at the same time fastens bearing caps to bearings, see fig. 5-1 page 5-3. Remove wing nuts and lift hopper up and off of bearings. Mark bearing caps and bearings to insure correct re-assembly as caps are interchangeable. Lift bearing caps off of bearings. Hinge gear cover open and lower. Remove feed roll link as explained in paragraph I. Feed roll assemblies can now be lifted out of bearings.

Loosen the set screws in the feed roll gear hubs and slide gears off of shafts, remove key from shafts. Loosen set screw in inner hub of clutch and slide clutch with lever off of shaft and remove key. Bushings are held in depositor on shafts with "O" rings. Remove "O" rings from grooves in shafts and remove bushings. Clean ends of shafts and coat with a film of non-toxic lubricant. Slide new bushings on shafts and secure position with the "O" rings. Replace keys in shafts and re-assemble by reversing the disassembly instructions.

3. TO REPLACE ADJUSTABLE ROCKER ARM BUSHING

Block up under finger shaft and table of frame near adjustable rocker arm side. Blocking should just touch shaft, no pressure. Remove feed roll link from stud as explained in paragraph I. Loosen the set screw in arm located on front face of arm adjacent to rock shaft, see fig. 5-1 page 5-3. This arm assembly weighs approximately 20 lbs., slide off of shaft. Press bushing out of arm and replace. Coat end of finger shaft with non-toxic lubricant, line up keyway in arm with key in shaft and slide unit onto rock shaft and finger shaft. Slide arm



FEED MECHANISM-TAKEN APART
FIGURE 5-1

PARTS REPLACEMENT - Cont'd.

on shaft until clearance between the arm face and stop collar on finger shaft is about the thickness of a piece of paper and lock set screw. Remove blocking and raise fingers and let drop, it must drop freely. Replace feed roll link, washer and detent pin.

4. TO REPLACE PLAIN ROCKER ARM BUSH.

The plain rocker arm is on the side of the depositor opposite of the adjustable rocker arm, see fig. 4-2 page 4-5. Block up finger shaft on plain rocker arm end, no pressure on shaft. Remove the screw that holds the spring attached to arm and let spring hang. The arm is held to shaft with two set screws, one at bottom and one at 90 degrees toward rear (charge end of depositor). Loosen screws approximately three turns and slide rocker arm off of rock shaft. Press out old bush and replace. Coat end of finger shaft with non-toxic lubricant, line up keyway in arm with key in shaft and slide arm onto rock and finger shaft. When arm is the thickness of paper away from shuttle lever, lock the two set screws in arm. Attach spring to arm, remove blocking from under finger shaft, raise fingers and let drop, it must drop freely.

5. TO REPLACE DRIVE BELT

Plug extension cord to power and turn "on" depositor. On charge end of unit turn the speed adjusting handwheel see fig. 4-3 page 4-5 counter-clockwise until unit is in its highest speed. Turn "off" depositor and pull extension cord out of receptacle. Reach into frame (charge end) and squeeze the belt together right behind the vari-speed pulley. This will pull the belt into the vari-speed pulley allowing slack around the large pulley and belt can be removed. Place new belt into vari-speed pulley, pull belt down into pulley to allow placing belt around large pulley. Turn vari-speed pulley by hand and belts will work out to the correct position in pulley.


6. TO REPLACE CONVEYOR BELTS

These belts are connected by hooked connectors. To replace, pull belt ends together and un-hook. Place new belts thru frame, up around pulleys and connect by pulling ends together and hooking.

7. TO REPLACE CONVEYOR CLUTCH

To replace the conveyor clutch it is necessary to disconnect conveyor belts as explained in paragraph 6 page 5-4. Remove the table on the charge end, see figure 5-2. The table is bolted to table hangers, two screws and nuts each side. Remove the four screws and nuts and lift table off of hangers. Move the right side hanger off of shaft end bearing (toward center of frame) and remove hanger from shaft. On left side loosen the set screw in hub of clutch and slide clutch to the right as far as it will go. Move the left side hanger toward the clutch (off of bearing) and remove from shaft. On the bottom of the clutch lever (square rod) is a screw and plain washer, remove. Pull out on adjusting knob (spring loaded) and slide downward until lever lock nut is off of clutch lever. The conveyor shaft rides in bronze bearings (one each end) that are held to the frame with flat head screws and hex nuts. Remove the screws and nuts while holding conveyor shaft and lift assembly out of frame. Remove end bearings from shaft. Slide clutch with the clutch lever assembly out of shaft.

The clutch lever assembly is attached to the face of the clutch with two screws, remove the screws and lever and attach to the new clutch face. Slide clutch and lever onto shaft up to shoulder on right, slide end bearing on each end (note oil hole in bearings towards top) and fasten end bearings to frame. Place table hangers on shaft and over end bearings and let hang. Slide clutch to enable placing lever lock nut up onto clutch lever and replace screw and washer at base of lever. Line up clutch so drive rod is parallel with its line of travel and lock set screw in hub of clutch. Replace table and fasten to hangers with the four screws and nuts.



SECTION VI

MOTOR

PARAGRAPH		PAGE NO.
1.	MOTOR TYPE	6-2
2.	BEARINGS	6-2
3.	MAINTENANCE	6-2
4.	LUBRICATION	6-2
	PRINCIPAL RENEWAL PARTS	6-3

CHARACTERISTICS & PERFORMANCE DATA

EQUIPMENT MANUFACTURE AND P/N Catalog #C202

MANUFACTURE GE

MASTER DRAWING Outline drawing #52a101469p2

CERTIFICATION DATA -----

AUXILIARY -----

EQUIPMENT MODEL NO. -----

QUANTITY -----

RATING (HP, VOLTS, PHASE) 1/4 Hp, 115/230V, 1Ø

INSULATION Class B

WEIGHT Est. 15 #s

CYCLES 60 HZ

DESIGN -----

TORQUE – STARTING 46.6 oz - ft

- FULL LOAD 12.2 oz - ft

AMPERES – STARTING 26.4 amps

- FULL LOAD 5.11 amps

POWER FACTOR -----

- F.L. 56.6%

- $\frac{3}{4}$ 49.4%

- $\frac{1}{2}$ 41.3%

- LOCKED 96.6%

ENCLOSURE DP

SERVICE 1.35

DUTY Cont.

TYPE KC

AMB. 40 degree C

F.L. K.W. -----

MOTOR FRAME 48

EQUIPMENT SPEC -----

EFFICIENCY FL Eff. 56.8

SYMBOL NUMBER -----

MOTOR TYPE

1. The motor supplied with the depositor is a fractional horsepower, single phase, capacitor start motor mounted in a resilient base for quiet operation. The capacitor start motor is almost identical to the split-phase motor, but delivers two to three times the starting torque per ampere of current. It is used on applications where heavy loads must be started and has a 1.35 service factor.

2. BEARINGS

All angle sleeve-bearing motors can be used over a wide range of applications, they can be mounted in any position and are quieter than ball-bearing motors.

3. MAINTENANCE

Motors properly installed are capable of operating for many years with reasonably small amount of maintenance. Before servicing motors and motor operated equipment, disconnect power supply from motor and accessories. Use safe working practices during servicing of equipment. Clean motor surfaces and ventilation openings periodically with a vacuum cleaner. Heavy accumulation of dust and lint will result in overheating and premature failure of the motor.

4. LUBRICATION

Motors are lubricated at the factory to operate for long periods under normal service conditions without relubrication. Excessive or too frequent lubrication may damage the motor. Lubrication instructions are usually found on the nameplate or terminal box cover fastened to the motor. Lubrication schedule for the motor are as follows:

- A.) Every three years of normal operation,
- B.) Every year for heavy duty service,
- C.) Every 25,000 hours of light duty operation

Oil plugs are on top of the two end bells. Remove the oil plugs and lubricate using SAE 10 non-detergent oil and replace plugs.



PRINCIPAL RENEWAL PARTS

G. E. 5KC36LN3 MOTOR

<u>QUANTITY</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>
1	CAPACITOR	8753704AR12

S E C T I O N VII

CONTROLLER

PARAGRAPH		PAGE NO.
1.	DESCRIPTION	7-2
2.	DEPENDABLE OVERLOAD PROTECTION	7-2
	PRINCIPAL RENEWAL PARTS	7-3

1. DESCRIPTION


General Electric's CR101H31 manual starter is for use on single phase fractional horsepower motors. It provides dependable overload protection for applications requiring no undervoltage protection. Typical applications include mixers, depositors, blowers, grinders, conveyors, presses, etc.

The starter has straight thru wiring (no need to loop around terminals) and has captive terminal screws. The flush plate carries a indicating light to inform operator that unit is "ON".

2. DEPENDABLE OVERLOAD PROTECTION

Positive bimetallic overload protection is provided by the thermal protection device which automatically opens contacts when an overload occurs and removes the motor from the line. Under overload conditions, the switch toggle moves to the mid-position, giving a positive indication that an overload has occurred. The bimetallic mechanism is completely trip-free so that contacts cannot be reclosed until the bimetallic strip cools. To restart after overload, turn starter to "OFF" and then to "ON".

The overload device includes a heater (a coil of resistance wire) that plugs in from front of switch and is keyed so it cannot be inserted the wrong way.



VIEW OF MANUAL STARTER
FIGURE 7-1

PRINCIPAL RENEWAL PARTS
G.E. CR101H31 MANUAL STARTER

<u>QUANTITY</u>	<u>DESCRIPTION</u>	<u>PART NO.</u>
1	OVERLOAD HEATER	CR123-H8.02A

CONTROLLER DATA

MANUFACTURE GE

MASTER DRAWING N/A

CERTIFICATION DATA N/A

RATING (VOLTS, PHASE, HP) 115/230V 1Hp Single Phase

SIZE 3.81 inches X 1.7 inches X 1.56 inches

OPERATON MANUAL

TYPE OPEN

FUNCTION MANUAL STARTER

DUTY CONTINUOUS

LOW - VOLTAGE FEATURE N/A

OVERLOAD RELAY

Heater Catalog No. To be specified

Type To be specified

Emergency Run (Yes/No) To be specified

AMBIENT DEGREES C N/A

ENCLOSURE OPEN

WEIGHT 1 lb.

EQUIPMENT SPECIFICATION N/A

LOCATION N/A

QUANTITY 1

WEIGHT

EQUIPMENT SPECIFICATION


LOCATION

QUANTITY


SYMBOL NUMBER

SECTION VIII

	PAGE NO.
WIRING DIAGRAM	8-2
DEPOSITOR ASSEMBLY	8-3



— WIRING DIAGRAM —
 17" & 24" HANDY C.D.



DET. NO.	PART NO.	NAME OF PART	DET. NO.	PART NO.	NAME OF PART	DET. NO.	PART NO.	NAME OF PART		
1	9-323	CASTER	45	9-320	SHUTTLE SPRING SPACER	94	9-371	CONVEYOR PULLEY		
A	4	NUT - 1/2-20 HEX	46	1-529	SHUTTLE BUMPER	95	9-372	CONVEYOR (TUBELT ASSEM.)		
B	4	WASHER - 1/2 PLAIN	A	2	SCREW - 1/4-20 X 3/8 PL. HD.	96	9-255	L.H. SUPPORT		
C	4	WASHER - 1/2 LOCK	47	9-1548	SHUTTLE	A	2	SCREW - 1/2-18 X 1/2 SOCK HD. CAP		
2	1	9-3112	FRAME	A	1	SCREW - 3/8-16 X 1/2 HEX. CAP	B	2	WASHER - 1/2 LOCK	
A	1	CONNECTOR - 3/8 STR. BOX	B	1	WASHER - 3/8 LOCK	C	1	SCREW - 3/8-16 X 1/4 SOCK DRE. PT.		
B	2	SCREW - 3/8-16 X 1 SOCK DRE. PT.	48	1-1043	SPRING CLIP	D	1	SCREW - 3/8-16 X 1/4 SOCK SET		
C	2	NUT - 3/8-16 HEX	A	2	SCREW - 8-32 X 1/4 RD. HD.	E	1	NUT - 8-32 HEX		
3	2	9-2188	ROLLER	49	1-1054	BACKING PLATE	97	1	DIE	
A	4	PIN - 3/16 X 1/4 TYPE 5 GROOV.	50	2-270	FEED ROLL GEAR	98	2	9-228	HOPPER HINGE PIN	
4	4	9-3170	END TABLE HANGER	A	2	SCREW - 3/8-16 X 3/8 SOCK SET	99	4	9-3204	FEED ROLL SHAFT BEARINGS
A	4	SCREW - 3/8-16 X 3/4 SO. HD. SET	51	1-5486	GEAR / SHUTTLE COVER	100	4	3573-4	LINEAR "O" RINGS	
B	4	NUT - 5/16-18 HEX JAM	A	3	SCREW - 1/4-20 X 3/8 RD. HD. 2 USE	101	1	9-3108	L.H. FEED ROLL SHAFT BRG.	
C	8	SCREW - 1/4-20 X 3/8 RD. HD. MACH.	F	1	NUT - 1/4-20 HEX	102	1	9-3095	DRIVE FEED ROLL ASSEM.	
D	8	NUT - 1/4-20 HEX	52			103	1	9-3004	DRIVEN FEED ROLL ASSEM.	
5	2	9-2300	PAN GUIDE	A						
A	4	SCREW - 5/16-18 X 1/2 THUMB	B			104	1	9-2134	FEED ROLL FRAME	
6	1	9-170-1	NAME PLATE	C						
A	2	SCREW - 8-32 X 3/8 RD. HD. MACH.	55			A	2	9-170-1	FIN - 4 X 1 TAPER	
7	1	9-311	FEED ROLL LINK	A						
A	1	SCREW - 1/4-20 X 3/8 SOCK SET	54	1	9-1270	SHUTTLE STUD	105	2	9-1577	DIE SCREEN
B	1	SCREW - 3/8-16 X 1/4 SOCK SET	55	1	9-2955	SHUTTLE LEVER	106	1	9-260	ROCK SHAFT LEVER
8	1	9-1938	UNIBAL SPHERICAL BRG LSSD	A	1	SCREW - 3/8-16 X 3/8 SOCK SET	A	2	SCREW - 3/8-16 X 3/8 SOCK SET	
9	1	9-3113	LINK STUD	B	2	SCREW - 3/8-16 X 1/4 SOCK DRE. PT.	107	2	9-191	FLANGE BEARING
10	1	9-314	DETENT PIN	C	2	NUT - 3/8-16 HEX	A	4	SCREW - 1/2-18 X 1/2 HEX. CAP	
A	1	WASHER - 3/8 PLAIN	56	1	9-1549	SHUTTLE TRACK	B	4	WASHER - 1/2 LOCK	
11	1	CLUTCH LEVER	A	2	SCREW - 3/8-16 X 1 HEX. CAP	108				
			B	2	NUT - 3/8-16 HEX	109	1	9-3472	CONVEYOR DRIVE SHAFT	
12	1	CLUTCH	C	2	WASHER - 3/8 LOCK	110	1	9-2520	STOP COLLAR	
13	1	9-3480	CLUTCH KEY	57	1	9-1591	ROCK SHAFT	A	1	SCREW - 3/8-16 X 3/8 SOCK SET
14	1	9-310	HOPPER	A	3	KEY - "D" WOODRUFF	B	2	SCREW - 3/8-16 X 1/4 SOCK DRE. PT. SET	
15	1	9-3099	R.H. FEED ROLL BRG. ASSEM.	58	1	9-3164	PLAIN ROCKER ARM	C	2	NUT - 3/8-16 HEX
16	1	9-2952	R.H. SUPPORT	A	2	SCREW - 3/8-16 X 3/8 SOCK SET	111	1	9-1625	RIGHT HAND FINGER
A	2	SCREW - 1/2-18 X 1 SOCK HD. CAP	59	1	9-3471	CONVEYOR DRIVE SHAFT BRG.	A	1	SCREW - 3/8-16 X 3/8 SOCK SET	
B	2	WASHER - 1/2 LOCK	60	1	9-3521	SHUTTLE LEVER SPRING	112	1	L-118	WIRE ADJUST. SCREW
C	1	SCREW - 1/8-16 X 1/4 SOCK DRE. PT.	A	2	SCREW - 1/8-16 X 1/4 SOCK SET	113	1	9-408	CUT-OFF WIRE	
D	1	NUT - 3/8-16 HEX	61	1	9-3473	CLUTCH LEVER	114	1	9-3232	FINGER SHAFT
17	1	9-320	ADJUST. BLOCK STUD	62	1	9-3505	PLAIN ROCKER ARM BUSH	A	2	KEY - "A" WOODRUFF
18	1	9-3206	ROCKER ARM BUSH	63						
19	1	9-3526	ADJUST. ROCKER ARM	64	1	9-3476	CLUTCH (WRAP SPRING)	B	1	COLLAR - 1/4 X 1/4 STD. SET
A	2	SCREW - 3/8-16 X 3/8 SOCK SET	A	1	SCREW - 1/4-20 X 1/4 SOCK SET	115	2	9-2999	L.H. SLIP FINGER	
B	1	SCREW - 3/8-16 X 3/4 THUMB	65	1	9-3478	CLUTCH LEVER	A	2	SCREW - 3/8-16 X 1/4 THUMB	
20	1	L-180	HAND KNOB	A	2	SCREW - 10-24 X 1/2 SOCK HD. CRP	116	2	9-2954	R.H. SLIP FINGER
A	1	PIN - 1/8 X 1 TYPE 1 GROOV.	B	2	WASHER - 1/8 LOCK	A	2	SCREW - 3/8-16 X 1/4 THUMB		
21	1	TOGGLE SWITCH W/AL HEATER	C	1	SCREW - 1/8-16 X 1/4 HEX. CAP	117	1	9-106	L.H. FINGER	
22	2	9-2777	CONVEYOR SHAFT BEARING	D	1	WASHER - 1/4 PLAIN	A	1	SCREW - 3/8-16 X 1/4 SOCK SET	
A	8	SCREW - 1/4-20 X 3/8 PL. HD.	66	1	9-3178	CONVEYOR SPEED GAGE	B	1	SCREW - 1/4-20 X 1/4 RD. HD. MACH.	
B	8	NUT - 1/4-20 HEX	67	1	9-3174	SPRING PLUNGER WING	C	1	NUT - 1/4-20 WING	
C	8	WASHER - 1/4 LOCK	A	2	SCREW - 1/4-20 X 1/4 SOCK SET					
23	2	9-3168	DROP TABLE	68	1	9-3175	SPRING PLUNGER			
24	1	9-235	GAUGE	69	1	2-235	COMPRESSION SPRING			
A	2	SCREW - 8-32 X 1/4 RD. HD.	70	1	9-3177	LEVER LOCK NUT				
25	1	9-246	FEED SCREW	A	2	PIN - 1/4 X 1/4 TYPE 1 GROOV.				
26	1	9-2536	ADJUSTING BLOCK	11	1	9-3172	LOCK NUT PIN			
A	1	FITTING - 1/8 ALUMITE WVD.	A	2	PIN - 3/32 X 3/4 COTTER					
27	2	9-348	LEATHER WASHER	3	2	WASHER - 1/2 PLAIN				
28	1	9-319	SPEED ADJ. HANDWHEEL	72	2	9-3091	ROD END BEARING			
A	1	SCREW - 3/8 X 5/8 SOCK DRE. PT.	73							
29	2	9-1182	BEARING SPACER	74	1	9-118	EXTENSION CORD			
30	4	9-1938	SEALMASTER BRG. RS-16	75	1	9-3163	MACHINE SPEED GAGE			
31	2	9-1934	FLANGE BEARING	76	1	9-313	ADJUSTING SCREW			
A	8	SCREW - 3/8-16 X 1 HEX. CAP	A	4	NUT - 3/8-16 HEX JAM					
B	8	WASHER - 3/8 LOCK	B	2	WASHER - 3/8 PLAIN					
32	1	9-3140	ROCK SHAFT LEVER STUD	77	1	9-3084	DRIVE ROD			
A	1	WASHER - 1/2 PLAIN	A	2	NUT - 1/2-20 HEX. JAM					
B	1	PIN - 1/8 X 1 COTTER	78	1	9-102	V-BELT				
33	1	MOTOR	79	1	9-123	DRIVEN SNEWE				
A	4	SCREW - 5/16-18 X 1 HEX. HD.	80	1	9-123	DRIVEN SNEWE				
B	4	WASHER - 5/16 PLAIN	81	1	9-123	BEARING WASHER				
C	4	WASHER - 5/16 LOCK	82	1	9-2212	DRIVE CHAIN				
D	4	NUT - 5/16-18 HEX	83	1	9-2993	DRIVEN SPROCKET				
34	1	9-314	MOTOR BASE	84	1	9-123	DRIVE SHAFT			
35	1	9-1930	MOTOR CORD	A	2	KEY - "A" WOD.				
36	2	9-3484	MOTOR BASE BUSHING	85	1	9-122	CRANK PINION			
37	2	201-M	BASE PIVOT BLOCK	A	1	SCREW - 3/8-16 X 3/8 SOCK SET				
A	2	SCREW - 1/4-20 X 3/8 HEX. CAP	86	1	9-1374	CRANK GEAR				
B	2	WASHER - 3/8 LOCK	A	1	SCREW - 3/8-16 X 1/4 SOCK SET					
38	1	9-311	PIVOT ROD	B	1	SCREW - 1/8-16 X 1/4 SOCK SET				
A	2	COLLAR - 5/8 STD. SET	87	1	9-3061	DRIVING LINK				
39	1	9-1230	ADJUST. SHAFT	A	2	FITTING - 1/8 X 1/8 ALUMITE				
A	2	9-2943	COLLAR - 5/4 STD. SET	88	1	9-185	CRANK PIN			
40	1	9-3167	SPEED GAGE	A	1	PIN - 3/16 X 1/4 COTTER				
41	1	9-1940	VARI-SPEED PULLEY	89	2	9-1933	UNIBAL SPHERICAL BRG.			
42	1	9-1229	DRIVEN SNEWE SHAFT	90	2	9-1184	BEARING WASHER			
A	2	KEY - "A" WOODRUFF	91	1	9-1184	DRIVE STUD				
43			92	4	9-376	COUPLING 2 TENSIONER				
44	1	9-324	SHUTTLE SPRING	93	1	9-118	CONVEYOR SHAFT			

STANDARD DEPOSITOR

DET. NO. 11 - 9-2604 CLUTCH LEVER
A - (U) SCREW - 1/4-20 X 1/4 HEX. CAP
DET. NO. 12 - 9-3376 WRAP SPRING-CLUTCH
A - (U) SCREW - 3/32 X 3/4 SOCK. SET.

DEPOSITOR W/40 TORQUE CLUTCH -
DET. NO. 11 - 9-2604 CLUTCH LEVER
A - (U) SCREW - 1/4-20 X 1/4 HEX. CAP
DET. NO. 12 - 9-1937 FORMING SPRING-CLUTCH

NEW CLUTCH LEVER
9-3484

NOTE!

MAGNETIC STARTER IS
AS PER ORDER, REPLACES
DETAIL. NO. 21

HANDY

VARIABLE SPEED DEPOSITOR

THE TATUMPA/MAGNA MIXER COMPANY

* STANDARD DEPOSITOR -
 DET. NO. 1 - 9-3004 CLUTCH LEVER
 A - (1) SCREW - 1/4-20 X 1/4 HEX. CAP
 DET. NO. 12 - 9-3776 WRAP SPRING-CLUTCH
 A - (1) SCREW - 1/4-20 X 1/4 SOCK. SET.

 * DEPOSITOR W/ M-TORQUE CLUTCH -
 DET. NO. 11 - 9-2949 CLUTCH LEVER
 A - (1) SCREW - 3/8-16 X 1/4 SOCK. SET
 DET. NO. 12 - 9-1577 FORMER SPRING OVER RUL. CLUTCH

 1 - NEW CLUTCH LEVER
 9-3484

NOTE!
 MAGNETIC STARTER IS
 AS PER ORDER, REPLACES
 DETAIL # 21

- HANDY -
 VARIABLE SPEED DEPOSITOR
 THE TRIUMPH/MAGNA MIXER COMPANY
 CINCINNATI, OHIO, 45240

(Insert Classification of TMDER Here) CLASSIFICATION:

REF: NAVSEAINST 4160.3A
NAVSEA S0005-AA-GYD-030/TMMP

NAVSEA/SPAWAR TECHNICAL MANUAL DEFICIENCY/EVALUATION REPORT (TMDER)			
INSTRUCTION: Continue on 8-1/2" X 11" paper if additional space is needed.			
1. USE THIS REPORT TO INDICATE DEFICIENCIES, PROBLEMS, AND RECOMMENDATIONS RELATING TO THIS PUBLICATION. 2. FOR CLASSIFIED TMDERS, SEE OPNAVINST 5510H FOR MAILING CLASSIFIED TMDERS. 3. SUBMIT TMDERS BY MAIL OR USE WEB SITE http://nsdsa.nswses.navy.mil			
1. PUB NO.	2. VOL./ PART	3. REV. NO./DATE OR TM CH. NO./DATE	4. SYSTEM/EQUIPMENT IDENTIFICATION
5. TITLE:			6. REPORT CONTROL NUMBER
7. RECOMMENDED CHANGES TO THIS MANUAL			
PAGE NO. A	PARA- GRAPH B.	C. RECOMMENDED CHANGES AND REASONS	
8. ORIGINATOR'S NAME AND WORK CENTER (Please Print)		9. DATE	11. TRANSMITTED TO
12. SHIP HULL NO. AND/OR STATION ADDRESS (DO NOT ABBREVIATE)		10. DSN/COMM NO.	13. EMAIL ADDRESS (Originator)

PLEASE CLOSE WITH TAPE — DO NOT STAPLE — THANK YOU

Fold Here

DEPARTMENT OF THE NAVY

Official Business

PLACE
POSTAGE
HERE

COMMANDER
CODE 5E30
NAVSURFWARCENDIV
4363 MISSILE WAY
PORT HUENEME, CA 93043-4307

Fold Here

(Insert Classification of TMDER Here) CLASSIFICATION:

REF: NAVSEAINST 4160.3A
NAVSEA S0005-AA-GYD-030/TMMP

NAVSEA/SPAWAR TECHNICAL MANUAL DEFICIENCY/EVALUATION REPORT (TMDER)			
INSTRUCTION: Continue on 8-1/2" X 11" paper if additional space is needed.			
1. USE THIS REPORT TO INDICATE DEFICIENCIES, PROBLEMS, AND RECOMMENDATIONS RELATING TO THIS PUBLICATION. 2. FOR CLASSIFIED TMDERS, SEE OPNAVINST 5510H FOR MAILING CLASSIFIED TMDERS. 3. SUBMIT TMDERS BY MAIL OR USE WEB SITE http://nsdsa.nswses.navy.mil			
1. PUB NO.	2. VOL./ PART	3. REV. NO./DATE OR TM CH. NO./DATE	4. SYSTEM/EQUIPMENT IDENTIFICATION
5. TITLE:			6. REPORT CONTROL NUMBER
7. RECOMMENDED CHANGES TO THIS MANUAL			
PAGE NO. A	PARA- GRAPH B.	C. RECOMMENDED CHANGES AND REASONS	
8. ORIGINATOR'S NAME AND WORK CENTER (Please Print)		9. DATE	11. TRANSMITTED TO
12. SHIP HULL NO. AND/OR STATION ADDRESS (DO NOT ABBREVIATE)		10. DSN/COMM NO.	13. EMAIL ADDRESS (Originator)

PLEASE CLOSE WITH TAPE — DO NOT STAPLE — THANK YOU

Fold Here

DEPARTMENT OF THE NAVY

Official Business

PLACE
POSTAGE
HERE

COMMANDER
CODE 5E30
NAVSURFWARCENDIV
4363 MISSILE WAY
PORT HUENEME, CA 93043-4307

Fold Here

(Insert Classification of TMDER Here) CLASSIFICATION:

REF: NAVSEAINST 4160.3A
NAVSEA S0005-AA-GYD-030/TMMP

NAVSEA/SPAWAR TECHNICAL MANUAL DEFICIENCY/EVALUATION REPORT (TMDER)				
INSTRUCTION: Continue on 8-1/2" X 11" paper if additional space is needed.				
1. USE THIS REPORT TO INDICATE DEFICIENCIES, PROBLEMS, AND RECOMMENDATIONS RELATING TO THIS PUBLICATION. 2. FOR CLASSIFIED TMDERS, SEE OPNAVINST 5510H FOR MAILING CLASSIFIED TMDERS. 3. SUBMIT TMDERS BY MAIL OR USE WEB SITE http://nsdsa.nswses.navy.mil				
1. PUB NO.		2. VOL./ PART	3. REV. NO./DATE OR TM CH. NO./DATE	4. SYSTEM/EQUIPMENT IDENTIFICATION
5. TITLE:				6. REPORT CONTROL NUMBER
7. RECOMMENDED CHANGES TO THIS MANUAL				
PAGE NO. A	PARA- GRAPH B.	C. RECOMMENDED CHANGES AND REASONS		
8. ORIGINATOR'S NAME AND WORK CENTER (Please Print)		9. DATE	10. DSN/COMM NO.	11. TRANSMITTED TO
12. SHIP HULL NO. AND/OR STATION ADDRESS (DO NOT ABBREVIATE)			13. EMAIL ADDRESS (Originator)	

PLEASE CLOSE WITH TAPE — DO NOT STAPLE — THANK YOU

Fold Here

DEPARTMENT OF THE NAVY

Official Business

PLACE
POSTAGE
HERE

COMMANDER
CODE 5E30
NAVSURFWARCENDIV
4363 MISSILE WAY
PORT HUENEME, CA 93043-4307

Fold Here

S6161-QQ-FSE-010

REVISION 1
